

Mantis Garment Measurements Summary 2018

The below measurements relate to actual garment. For further measurements or size guide, please contact Mantis World

M92 Women's Loose Fit Vest	S	M	L	XL
1/2 Chest measured 2.5cm below armhole	45,5	48	50,5	53
Front length	66	68	70	72
Back length	68	70	72	74

The 1/2 chest is measured 2.5 cm below the arm hole and straight across.

Length is measured from the HPS (high point shoulder) i.e. top of shoulder seam adjacent to neck, to bottom of hem