


WORK-GUARD

by **Result**[®]

R337X - SPARK SAFETY TRAINER INNER SOLE LENGTH/WIDTH



A = INSOLE LENGTH FROM INNER HEEL CURVE TO LONGEST POINT AT TOE
B = INSOLE WIDTH ACROSS WIDEST PART.

SIZE		LENGTH	WIDTH
UK	EURO	A	B
6	40	25.1	9.0
7	41	25.6	9.0
8	42	26.5	9.2
9	43	27.0	9.2
10	44.5	28.0	9.2
11	46.0	28.5	9.3
12	47	29.1	9.5

Measures given in Cms