


# WORK-GUARD

by **Result**<sup>®</sup>

## R347X - SHEILD LIGHTWEIGHT SAFETY TRAINER INNER SOLE LENGTH/WIDTH



A = INSOLE LENGTH FROM INNER HEEL CURVE TO LONGEST POINT AT TOE  
B = INSOLE WIDTH ACROSS WIDEST PART.

SIZE		LENGTH	WIDTH
UK	EURO	A	B
6	40	25.3	9.2
7	41	26.0	9.5
8	42	26.5	9.5
9	43	27.0	9.7
10	44.5	28.0	10.0
11	46.0	28.5	10.0
12	47	29.0	10.2

Measures given in Cms